pure fun®

simply good products for real life™

Pure Fun 15’ Trampoline/Enclosure Set
Model No. 9015TS
Owner’s Manual

Please read all the instructions before using this product.
Consult a physician before beginning any exercise program or strenuous activity

WARNING

250 LBS
MAXIMUM
WEIGHT RATING

WARNING

This product is not suitable for children under 3 years of age. It contains small parts which may cause choking.

Do not allow more than one person on the trampoline at any time.
Do not allow small children to use unless supervised by an adult.
ADULT ASSEMBLY REQUIRED.

The SAFETY NET is intended only to REDUCE the risk of injury from falling from the trampoline. It is NOT a rebounding device.

Pure Fun is a Trademark of
Pure Global Brands, Inc.

pure™ global brands inc.

OWNERS MANUAL
CUSTOMER SERVICE INFORMATION

Thank you for purchasing our **Pure Fun™ 15' Trampoline/Enclosure Set**.

At Pure Global Brands, we want all of our customers to be completely satisfied with their purchase. Please take time to review the contents of the product you just received to make sure that all of the parts are included. If you find that any parts are missing or damaged, we will happily provide replacement parts at no charge within 30 days of purchase. Please keep in mind that for select damaged part replacement requests, we will require a photo for submission to our quality control office.

To order these parts, or if you have any other questions or concerns about this Pure Global product, please e-mail the Pure Global Brands, Inc. customer service department at customerservice@puregbi.com or contact us at 1-866-498-5269. You can also visit our website at: www.pureglobalbrands.com

If you request replacement parts, please be sure to include the following information in your correspondence:

YOUR NAME
YOUR MAILING ADDRESS
YOUR EMAIL ADDRESS
RETAILER WHERE YOU PURCHASED PRODUCT
DATE OF PURCHASE
ORDER # (IF AVAILABLE)
PRODUCT MODEL #: 9015TS
SERIAL #
PRODUCT NAME: 15 Foot TRAMPOLINE/ENCLOSURE COMBO SET
PART # (located in manual)
QUANITITY NEEDED
PICTURE OF DAMAGED PART(s) – SUBMIT VIA Email , Fax, or Mail

Again, thank you for purchasing a Pure Global Brands product.

Sincerely,
Customer Service
Pure Global Brands, Inc.
1-866-498-5269

LIMITED WARRANTY

Pure Global Brands, Inc. warrants this product to be free from defects in workmanship and materials under normal use and conditions for the duration of the period outlined below FROM THE DATE OF ORIGINAL PURCHASE. This Limited Warranty is not transferrable and is available only for the original purchaser of the Product. The Company's obligation under this warranty is limited to replacing or repairing the Product, at the discretion of the Company.

The various components of the trampoline/enclosure are warranted against defects and workmanship for the following time period(s):

- **Steel Frame: 2 Years**
- **Frame Pad: 6 Months**
- **Jumping Surface: 1 Year**
- **All Other Parts: 90 Days**

All warranty coverage extends only to the original retail purchaser from the date of purchase. Pure Fun's obligation under this Warranty is limited to replacing or repairing, at Pure Fun's option, the product at one of its authorized service centers. All products for which a warranty claim is made must be received by Pure Fun at one of its authorized service centers and accompanied by sufficient proof of purchase (photocopy of the original store receipt, indicating the date of purchase). All freight and handling fees are the responsibility of the consumer to pay, both to and from Pure Fun. All warranty claims must be preauthorized by Pure Fun. Preauthorization can be obtained by calling 866-498-5269. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage, or repairs not provided by a Pure Fun authorized service center or for products used for commercial or rental purposes. This warranty does not cover ordinary wear and tear, weathering, failure to follow directions, improper installation, improper maintenance, or acts of Nature (such as damage caused by wind, lightning, snow, water, or ice). Weather damage, damage caused by unauthorized repair work or damage caused by improper use of the products are not covered by the product warranty. No other Warranty beyond that specifically set forth above is authorized by Pure Fun.

PURE FUN IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND PURE FUN SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NO APPLY TO YOU.

This warranty gives you specific legal rights. You may also have other rights, which vary from state to state.

WARNING

CHOKING HAZARD – Small parts

NOT for children under 3 years.

! Warning!

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risks of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

WARNING
IMPORTANT – PLEASE READ!

WARNINGS – GENERAL SAFETY ADVICE

Ensure the trampoline has been assembled correctly, per the instructions in the manual.
It is essential that the intended site for this trampoline is completely flat and level. If the ground is not level this will cause movement in the frame and could cause stress on the joined sections.
This trampoline set is over 1 foot 5 inches (51cm) tall. It is only recommended for use by children **6 + YEARS OF AGE.**
DO NOT exceed the recommended **MAXIMUM WEIGHT** limit of 250lbs (113kgs).
DO NOT allow more than one person on the trampoline at a time.
DO NOT wear glasses or helmets when using the trampoline.
DO NOT use the trampoline in wet, windy or other adverse weather conditions.
DO NOT somersault – this can cause serious injury, resulting in paralysis or death.
DO NOT allow other persons to go under, sit, stand or lie on the trampoline or the frame pads while the trampoline is in use.
DO NOT use the trampoline set when under the influence of alcohol, drugs or medication which may impair the jumper's judgement and coordination.
ALWAYS wear socks when using the trampoline.
ALWAYS remove jewelry, belt buckles, or any other sharp objects before using the trampoline.
ALWAYS jump in the middle of the trampoline bed.
ALWAYS follow the safety warnings stated with your trampoline instructions.
ALWAYS secure the trampoline against unauthorized and unsupervised use.
NEVER wear footwear (e.g. shoes) when using the trampoline.
Children **MUST NEVER** use the trampoline set unless supervised by a responsible adult with knowledge of trampoline use.
Children **MUST NEVER** be left unattended at any time.
Before using this product, inspect and replace any worn, defective or missing parts.
Ensure the trampoline is on level ground with a minimum of 8 feet (2.5M) clear space around the sides, 26 feet (8M) clear height space above and that no obstructions are under the trampoline.
ALWAYS watch for power lines, overhead cabling, and other hazards or obstructions above, around and below the location where you are installing your trampoline set. Failure to do so can result in serious injury, death, and property damage for which Pure Fun is not liable.
Ensure the Enclosure frame has been assembled correctly per the instructions in the manual. .
This Enclosure is **NOT** a rebounding device, and it should **NEVER** be used for any other purpose (play pen, dog run, etc.) or in a manner inconsistent with the information outlined in this manual.
Children **MUST NEVER** be left unattended inside the Enclosure.

(continued on next page)

WARNING
IMPORTANT – PLEASE READ!

WARNINGS – GENERAL SAFETY ADVICE

We only recommend using the Enclosure with Pure Fun™ Trampolines. Any alterations to the construction or materials of this Enclosure or deviations from the assembly instructions may result in unforeseeable safety compromises, and the consumer assumes all responsibility for doing so.

ALWAYS ensure the entrance to the Enclosure is fully closed and secure before jumping on Trampoline.

NEVER use the Enclosure Poles or Safety Net as a handhold or grip to assist in entering or exiting the trampoline. This will result in damage to your Enclosure, for which Pure Fun™ is not responsible.

ALWAYS enter and exit the enclosure through the zippered opening ONLY; use caution to prevent falls and/or accidental strangulation.

NEVER attempt to crawl under or climb over the Safety Net to enter/exit the Enclosure area.

If the Safety Net material, Zipper or any other part of the Enclosure becomes damaged, cease using the trampoline immediately. Either remove the Net and Enclosure frame from the trampoline entirely and continue use at your own risk, or cease use until you obtain the necessary replacement parts.

This Safety Net and Enclosure is **ONLY** intended to help prevent accidental falls from the trampoline mat/bed, and then **ONLY** during recommended jumping exercises as described in Pure Fun™ Trampoline manuals.

NEVER attempt to rebound off of, swing or hang from the Safety Net or Enclosure poles, nor intentionally attempt to jump into or over the netting, as this may result in serious injury, paralysis or death and severe damage to the Enclosure and Trampoline. Pure Fun™ will not be responsible for any damage to the Trampoline and Enclosure or consequential injuries resulting from these practices.

NEVER let children take items or toys into the Enclosure.

ALWAYS remove jewelry, belt buckles, sharp objects, before entering the Enclosure.

NEVER wear loose fitting clothing, items, or articles with hooks, loops, or any features which can easily become snagged in the Safety Net.

Mount and dismount from the trampoline and enclosure with care as injury may result. Children should be assisted when entering and existing the trampoline to reduce the risk of falling.

The frame of your trampoline set is made of steel and it will conduct electricity. No electrical equipment (lights, heaters, etc.) should be permitted on or around the trampoline under any circumstance.

Please read and refer to other warnings and use information in the trampoline instructions before use.

Dispose of all packaging materials safely and per local ordinance.

It is possible for the Trampoline and Safety Net to be blown about by high wind. If you anticipate high winds, the Trampoline and Safety Net should be moved to a sheltered location, or be disassembled. Pure Fun™ is not responsible for any damage resulting from wind or extreme weather.

See last page of this manual for information on purchasing an Anchor Kit to help secure your trampoline against moderate to high winds.

TRAMPOLINE PLACEMENT

The minimum overhead clearance required is 26 feet (8 meters). Ensure that no hazards or obstructions are near the trampoline such as tree branches, swing sets, swimming pools, electrical power wires, walls, fences, roof overhangs etc.

Please be aware of the following when selecting a place for your trampoline set:

- Trampoline must be placed on a level surface
- The area must be well-lit.
- All obstructions from overhead, underneath or around the trampoline set must be removed.
- Do not use this trampoline set indoors.
- Do not use this trampoline set on any slippery/smooth floor surface, uneven or sloping ground surface
- Do not place the trampoline set on hard surfaces, such as asphalt, stone, concrete etc, as this can damage the frame

You increase the risk of serious injury and/or death if you do not follow these guidelines.



Care & Use

This trampoline must be assembled by adults. It must be erected exactly as detailed in the assembly instructions. Two adults are required to assemble this trampoline. This product should only be used by children over the age of 6. Please ensure children under the age of 3 years old do not play with or are given any part of this trampoline when being assembled or when complete as it contains small parts which may pose a choking hazard.

Please take care during assembly, as the manufacturing process can sometimes result in the occasional sharp edge and small pieces of waste metalwork. The use of gloves to protect your hands from pinch points during assembly is also strongly recommended. Should there be any missing parts; the trampoline must not be used until replacement parts have been fitted.

Your trampoline must be placed on a flat and level surface which is well-lit. Under no circumstances should it be positioned on a hard surface such as concrete or asphalt, unless the ground under the trampoline plus the recommended free space area is covered with a safety surface. Examples of suitable surfaces are grass, sand or a play surface intended for this trampoline. It is important not to place or store anything under your trampoline.

USAGE:

This trampoline is designed and made for family domestic use only within the recommended weight limit of 250lbs (113kg). This trampoline is not intended for use outside of these guidelines. The user must remove footwear (shoes) before use. The user must wear socks when using the trampoline. Misuse can result in injury. Inspect the trampoline before use and always replace worn, defective or missing parts. The frame pad should always be fitted properly, fully covering the trampoline frame and springs.

Supervision

Children must always be supervised while they are playing on the trampoline and must be instructed not to use the trampoline in an inappropriate or hazardous manner.

Remember!

Trampolines are rebounding devices which propel the user to unaccustomed heights, and into a variety of body movements. Rebounding off of the trampoline and striking the frame or springs, intentionally bounding into the enclosure net, or improperly landing on the trampoline mat (bed) may cause serious injury.

Safety Information: This trampoline is designed and manufactured to provide you and your family with many years of fun and exercise, but for your benefit and safety, please read this manual carefully and in full before assembling and using your trampoline.

DO NOT allow more than one (1) person on the trampoline at a time. Multiple jumpers increase the chance of someone becoming injured. Jumpers may collide with one another, fall off the trampoline, fall on or through the springs, or land incorrectly on the mat. Multiple jumpers increase the chances of loss of control, collision, and falling off. This can result in severe injury or death.
Always secure the trampoline against unauthorized and unsupervised use.

The frame of your trampoline is made of steel and it will conduct electricity. No electrical equipment (lights, heaters, extension cords, household appliances, etc.) should be permitted on or around the equipment under any circumstances to avoid the risk of electrocution.

As your trampoline mat is raised off the ground, there is the risk of falling when entering or exiting the trampoline. Children should be assisted when entering and exiting the trampoline to reduce their risk of falling.

Do not flip, somersault or perform maneuvers which may cause you to land on the head or neck. Paralysis or death can result even if you land in the middle of the trampoline mat (bed).

We recommend that the user does not wear loose-fitting clothing or jewelry that may catch or snag during play. Children should NOT wear helmets while playing on the trampoline. Ensure that children do not walk or crawl underneath the trampoline even when not in use. Keep the area around and underneath free from all objects and obstacles at all times.

IMPORTANT: You must not use the trampoline if you have a medical history of neck or back injuries or a mental or physical condition – an existing condition or injury dramatically increases the risk of serious injury or death.
No modification should be carried out to the trampoline or any of its components. Any modification could lead to damage to the product or result in a personal injury.

WEATHER CONDITIONS: Special care should be taken as weather conditions change. In particular, a wet trampoline mat (bed) is too slippery for safe jumping. Gusty or severe winds can cause jumpers to lose control. To reduce the chance of injury, use the trampoline only under appropriate weather conditions. In cold weather, tongues and lips can stick to metal at sub zero temperatures. In warmer and sunnier weather, parts can become extremely hot, and the temperature should be regularly checked during play, especially metal parts.

HIGH WINDS: It is possible for the Trampoline to be blown about by high wind. If you anticipate high winds, the Trampoline **must** be moved to a sheltered location, or be disassembled. Pure Fun™ is not responsible for any damage to property or product resulting from wind or extreme weather.
See last page of this manual for information on purchasing an Anchor Kit to help secure your trampoline against moderate to high winds.

JUMPER'S ROLE IN PREVENTING ACCIDENTS

Education is the key to safety. Read, understand, and practice all safety precautions and warnings prior to using the trampoline. A controlled jump is when you land and take off from the same point on the mat. For additional safety tips and instructions, contact a certified trampoline instructor
Stay in control of your jumps. DO NOT move onto more complicated or more difficult maneuvers until you have mastered the basic, fundamental bounce.
Always bounce in the middle of the bed. Bouncing near the edge of the bed can lead to injury and can also stretch the springs. The frame pad is not designed nor intended to support the weight of the trampoline user. Do not step or jump directly onto the frame pad.
Avoid bouncing too high. Stay low until you can control your bounce and land consistently in the middle of the bed.
To regain control and stop your jump, bend your knees quickly when you land.

Do not use the trampoline or supervise a child's use of the trampoline when under the influence of alcohol, drugs or medications.
Allow each jumper a brief turn on the trampoline. Extended bouncing exposes an over tired user to an increased risk of injury.

The trampoline mat is several feet from the ground. Jumping off the trampoline to the ground or any other surface may result in injury. Jumping onto the trampoline from a roof, deck, or other object also represents a risk of injury. Smaller children may need assistance getting up on or down from the trampoline. Mounting and dismounting properly should be a strict rule from the very beginning. Users should climb onto the trampoline by placing their hands on the frame and stepping or rolling up onto the frame, across the springs, and onto the mat (bed). Do not step directly on the frame pad or grasp the frame pad when mounting or dismounting the trampoline. Users should always place their hands on the frame while mounting or dismounting. To dismount, jumpers should walk to the side of the mat (bed), bend over and place one hand on the frame, then step from the mat to the ground. Injury may result from hitting the frame or falling through the springs while jumping or getting on or off the trampoline. Stay in the center of the trampoline mat when jumping. BE SURE TO KEEP THE FRAME PAD IN PLACE TO COVER THE FRAME AT ALL TIMES. The frame pad is not designed nor intended to support the weight of the trampoline user. Do not step or jump directly onto the frame pad

SUPERVISOR'S ROLE IN PREVENTING ACCIDENTS

The trampoline is designed and made for family domestic use only by people 6 years and older.

It is the responsibility of the supervisor(s) of trampoline users to provide knowledgeable and mature supervision. Do not supervise a child's use of the trampoline when under the influence of alcohol, drugs or other medications. A supervisor needs to know and enforce all the rules and warnings set forth in this manual in order to minimize the likelihood of accidents and injuries and to inform users of these rules. During periods of time when supervision is unavailable or inadequate, this may require that the trampoline be disassembled, placed in a secure area, or otherwise secured against unauthorized use. It is the responsibility of the supervisor(s) to be sure that the users are fully aware of the safety guidelines which are printed on the pads.

DISPOSAL INFORMATION

Never allow the trampoline parts to be placed or used near a fire. If it becomes necessary to dispose your equipment, remove springs and disassemble. Store safely & out of reach of children until it can be properly disposed of. Remember to dispose it in a safe place and manner so as not to present any safety hazards.
Check with your local recycler or retailer for recycling or disposal advice.
These instructions are issued in the interest of general safety for the public.

!WARNING!

Misuse and abuse of this trampoline is dangerous and can cause serious injury or death

IMPORTANT

It is essential that the intended site for this trampoline is completely flat and level. If the ground is not level this will cause movement in the frame and could cause stress on the joined sections. The recommended safe play area is 8 feet (2.5m around the trampoline on all sides and 26 feet (8m) above the top.

REMOVE all obstacles from play area. A safe play area must be on level ground, free from all structures, landscaping, trees and branches, rocks, wires, sprinkler heads and other obstacles. Children can be seriously injured running or colliding into such obstacles.

NO MORE THAN ONE PERSON AT A TIME ON THE TRAMPOLINE!! MULTIPLE JUMPERS WILL INCREASE THE RISK OF INJURY SUCH AS BROKEN NECK, LEG, BACK OR HEAD INJURY.

DO NOT PERFORM SOMERSAULTS (FLIPS) AS THIS WILL INCREASE RISK OF LANDING ON HEAD OR NECK RESUTLING IN INCREASED RISK OF SERIOUS INJURY OR DEATH.

ADULT ASSEMBLY REQUIRED



TWO ADULTS ARE REQUIRED TO ASSEMBLE

To assemble this trampoline you will need to use the included Spring Tool.
Do not discard or misplace Spring Tool. You will need this to remove/replace springs if required.

Please read the following instructions carefully prior to assembly.

As these are assembled separately, the assembly instructions/parts list for the trampoline are below, followed by the enclosure assembly instructions/parts list on Page 19.

Assemble your trampoline FIRST. Then assemble and attach the enclosure.

PRIOR TO ASSEMBLING:

Please refer to the table for part descriptions and numbers.
The assembly instruction uses these descriptions and numbers as reference.
Make sure you have all parts listed. If you are missing any parts, please contact customer service at customerservice@puregbi.com or by calling 866-498-5269.
Choose a location on level ground and free from obstacles where you will be installing your trampoline.
Assemble the trampoline in the location it will be installed in to ensure proper fit and clearance from environmental objects. If the trampoline must be moved once it is assembled, you **MUST** use a **MINIMUM of 3** adults placed equidistant around the unit, making sure to keep it level as it is lifted. Failure to do so will result in damage to the assembly.

!NEVER DRAG THE ASSEMBLED TRAMPOLINE!

IMPORTANT: USE GLOVES TO PROTECT AGAINST PINCH POINTS DURING ASSEMBLY.

PARTS LIST - 15' Trampoline - 100 Springs - (Enclosure parts list on page 19)

Reference Number	Part Number	Description	15'
1	TR800	Trampoline Mat	1
2	TR801	Frame Pad	1
3	TR802	Top Rail	10
4	TR803	T-Section	10
5	TR804	"W" Leg Base	5
6	TR805	Vertical Leg Extension	10
7	TR806	Springs	100
8	TR807	Safety Instruction Placard	1
9	TR808	Spring Tool	1

Enclosed are the current specifications and product features available at time of printing, however, changes may be made in equipment, availability, specifications and features without notice.

1.
2.
3.
4.
5.
6.
7.
9.

WARNING: READ AND FOLLOW THESE INSTRUCTIONS, PRIOR TO ASSEMBLY AND USE OF THIS EQUIPMENT.

ASSEMBLE TRAMPOLINE WHERE YOU WILL BE INSTALLING IT.

ONCE IT IS ASSEMBLED, MOVING YOUR TRAMPOLINE REQUIRES THAT YOU USE AT LEAST 3 ADULTS PLACED EQUIDISTANT AROUND THE TRAMPOLINE.

IF IT MUST BE MOVED, YOU MUST LIFT WHILE KEEPING IT LEVEL TO AVOID DAMAGE TO THE UNIT.

MOVING THE TRAMPOLINE FOR MEDIUM/LONG DISTANCES AND/OR OVER UNEVEN GROUND REQUIRES THAT YOU TAPE THE TOP RAIL FRAME JOINTS TO PREVENT SLIPPAGE.

!!NEVER DRAG YOUR TRAMPOLINE IN ORDER TO MOVE IT!!

STEP 1 – FRAME LAYOUT

Check that you have received all parts using the relevant illustrations below. All parts with the same part # are interchangeable and do not have “right” or “left” section,

THIS TRAMPOLINE HAS 5 LEGS



STEP 2 – TOP RAIL AND SUPPORT ASSEMBLY

1. Slide T-section (#4) onto flattened end of the top rail (#3). Ensure the hole on the side of the T-section matches up with the hole on the side of the top rail. If necessary, use the spring hook tool to help you widen the T-section so it slides easily on the top rail. Repeat for the other T-sections,
but do not connect the top rail sections together yet.

IMPORTANT: The holes on the top rail (Part #3) need to be facing DOWN. You should not see them when sliding the T-Sections onto the top rail.



Fig. 1

2. **Make sure you are not able to see any holes in the top rail sections before proceeding.**
Using the spring hook tool to hold the T-section closed, fit the leg tubes (#6) over the shut T-sections. You may need to use a rubber mallet (not included) to assemble the Leg Extensions down onto the T-sections so that the flanged part of the tube is resting as close as possible to the T-section base.
Note: The orientation of the leg tubes is important (The flanged end needs to fit the T-sections). The T-sections must be inserted into the wider end of the leg tubes. Be careful not to pinch your fingers when compressing the T-sections.



Fig. 2

3. Connect two top rail sections together. Repeat for the other top rail sections as shown in Fig 3.


Fig. 3

4. Fit the W-shape Leg Bases (#5) onto the Leg Extensions (#6) as shown in Fig 4. Make sure they fit securely into place. Fit the remaining tubes (#5) using these instructions.



Fig. 4

5. Turn over the 4 sub-assembled sections and connect them together. Note that at this stage the sections can still become easily separated. The assembly will become rigid only when the trampoline mat is assembled to the frame.


Fig. 5

6. The completed frame should look the same as fig.6.


Fig. 6

IMPORTANT!

It is essential that the intended site for this trampoline is completely flat and level. If the ground is NOT level this will cause movement in the frame and damage the trampoline or cause serious injury.

ONCE YOUR TRAMPOLINE IS ASSEMBLED, MOVING IT REQUIRES THAT YOU USE AT LEAST 3 ADULTS PLACED EQUIDISTANT AROUND THE TRAMPOLINE. DURING THE MOVE, YOU MUST LIFT WHILE KEEPING IT LEVEL TO AVOID DAMAGE TO THE UNIT. MOVING THE TRAMPOLINE FOR MEDIUM/LONG DISTANCES AND/OR OVER UNEVEN GROUND REQUIRES THAT YOU TAPE THE TOP RAIL FRAME JOINTS TO PREVENT SLIPPAGE.

!!NEVER DRAG YOUR TRAMPOLINE IN ORDER TO MOVE IT!!

STEP 3 – TRAMPOLINE MAT ASSEMBLY

WARNING: Be careful where you place your hands etc. during spring assembly as connector points can pinch!

When attaching springs to the trampoline mat, you will need another person to help you with this part of the assembly.

7. Lay out the Trampoline Mat (1) inside the frame
The white cross/Logo and safety labels should be facing upwards



HOW TO USE THE SPRING TOOL

STEP 1: (Select your spring type A or B).
Attach tool to the other spring hook with hook end of the tool. The hook end is located on the end of one of the tool handles.

STEP 2: With the spring attached, pull the tool towards the frame, extending the spring so it can be hooked into its corresponding spring hole in the top rail frame.



The following figures show how to connect the springs and tighten the trampoline mat as evenly as possible:

A. Using a “clock” as a relative guide, choose a point that represents 12 o’clock on your jump mat. Attach the spring to the V-ring of the jump mat. Attach the hook end of the tool to the other end of spring as shown in the directions on the previous page, and line up to the spring hole. Pull the tool and attach the spring hook so it links up to the hole in the top rail. Following the diagram on the right, repeat this at the 6 o’clock, 3 o’clock, and then 9 o’clock points.

B. Repeat this process to attach the remaining springs in a similar way. It is **VERY IMPORTANT** that the trampoline mat should tighten as equally as possible. To achieve this, make sure that you always attach two springs across from each other, otherwise you will not be able to attach all the springs due to the tension on the trampoline mat. The tension will increase with the number of attached springs.

C. If you notice that a spring is not hooked directly to its corresponding hole in the top rail, but the tension is too great to currently move it, leave the **V-Ring empty on the jump mat** that the hole in the top rail should have been hooked to. Remember to also leave **the hole in the top rail** empty that the current, incorrectly installed spring should have been hooked into so that this spring can be inserted there when tension allows for correction of this issue.

D. After assembly, the space between all springs should be equal.

E. If you notice that you have skipped a hole and/or V-Ring connection, recount and remove or attach any springs required. NEVER leave spaces on the V-Rings on the jump mat or empty holes on the top rail.



STEP 4 – SAFETY PLACARD ATTACHMENT

A. Using the tie wrap, attach the Safety Instruction Placard (8) to the trampoline. The tie wrap should go around the Vertical Frame joint and the Top Rail to ensure it remains attached.



STEP 5 – FRAME PAD ASSEMBLY

You will need 2 adults to assemble the frame pad to keep it even during installation.

A. Lay the Frame Pad (2) over the trampoline so that the springs and the steel frame are covered. Ensure that the Frame Pad covers all metal parts.

B. Make sure that the stitched flap of the frame pad is able to be folded under the top rail.

C. Attach elastic bands to the tramp mat as shown in figure C, but do **NOT** pull them too tight or they will break off after a period of use. **The bands require a certain amount of slack, as they are attached to the jumping surface which will have significant vertical movement during use. Failure to leave slack in the bands will result in the bands tearing loose from the pad, and/or the pad shifting off of the top rail upon use.** For stability you should also cross the band under itself when looping it around the top rail to prevent wear and tear on the stitched ends of the elastic bands.

D.Once bands are secured, pull drawstring so the stitched flap fits under the top rail.

E.The trampoline pad should be the slightest bit loose so it “floats” a bit with movement. **Keep in mind it will require readjustment after a period of use.**

F. STOP using the trampoline if it shifts during use, and have an adult readjust it.



Enclosure Parts List & Assembly Instructions on Next Page

Enclosure Parts List & Assembly Instructions

Parts List - 15' Enclosure - 10 Poles

Part Number	Description	15' (5 Legs)
1	Upper Pole	10
2	Lower Pole	10
3	Steel Jig	20
4	Screw Set	40
5	Safety Net	1
6	Spacer	20
7	Pole Cover	10
8	Pole Cap	10
9	Safety Nut	40
10	Wrench	1

PARTS DIAGRAM FOR ENCLOSURE

1. Upper Pole

2. Lower Pole



3. Steel Jig

4. Screw Set

5. Safety Net



6. Spacer



7. Pole Cover

8. Pole Cap



9. Safety Nut

10. Wrench

Read the Safety Warning information on Page 5 before assembling or using your Enclosure.

STEP 1 – Pole Assembly

A. Put the Upper (1) and Lower (2) sections of the Enclosure Poles together as shown below.
B. If necessary, attach the Pole Caps (8) to the tops of each Enclosure Pole.
C. Slide the Pole Covers (7) over the connected Enclosure Poles.



STEP 2 – Attach Poles to Trampoline

Note: Each Enclosure Pole requires **2x U-Shaped Bar & Metal Plate assemblies** to attach it to a Trampoline leg. For positioning, the Enclosure Pole bottoms should reach the base of the Trampoline legs, with the rubber feet securely on the ground.

A. As shown in Diagrams A1 and A2 below, place the Enclosure Pole against the Trampoline leg, making sure to place the Spacers between each pole and leg.
B. Insert each U-shaped Bar through the plastic Spacers and into the Metal Plates. MAKE SURE that the U-Shaped bar has its threaded ends facing **towards the center** of the trampoline, and **not outwards**. Position the lower U-Shaped bar near the bottom of the Trampoline leg, but **above** any bend in the tubing. Position the upper U-Shaped bar near the top of the Trampoline leg, but **under** the T-section flange (Pure Fun Trampolines only), or other fastening array.
C. Secure U-Shaped Bar to Metal Plates with Nuts (4). Once fully tightened, place Safety Cap on each end.
D. Once the assembly has been completed properly, the support poles should resemble the bottom right diagram below.







STEP 3 – Attach Safety Net Top

A. Locate the section on the Safety Net with the zippered “doorway” and align it to the desired position you want it to be at on the trampoline.
B. Make sure you note that the sewn edge with the elastic bands w/hooked-ends is the bottom of the net.
C. Locate the edge with the pre-sewn hanging loops (the upper edge) and hook a loop at the top of each pole. (See Diagrams B1 and B2)
D. C. Once the assembly has been completed properly, the Safety Net should resemble the diagram below.



NOTE: Using the below diagrams, locate your Enclosure Hook type and follow these corresponding instructions when attaching the enclosure bottom as instructed in **STEP 4- Attach Safety Net Bottom**



STEP 4 – Attach Safety Net Bottom

A. Hook the Net to the V-Rings on the trampoline mat **in the direction shown in the diagram below**.
B. The Safety Net will begin to be pulled taut, and tighten around the frame as you proceed. **Use caution on pinch points**, and apply the necessary force to attach the remaining bands to the V-Rings.
NEVER pull the Safety Net from the mesh netting, as the fabric may tear. Always pull the net from the sewn seam.



C. As mentioned above, the Safety Net will become very tight as you near completion. It can be helpful to have another adult assist you in completing this process. The Safety Net should be very tight and will stretch enough to wrap around the frame, but be careful not to pull too hard from the netting or the bands themselves--try to direct most of the force from the sewn edges.

IMPORTANT CHECK LIST AFTER COMPLETION OF ENCLOSURE ASSEMBLY

1. **ENSURE THAT ALL ATTACHMENT HOOKS ARE STRETCHED TIGHT**
2. **ENSURE THAT ALL JIGS ARE FASTENED SECURELY**
3. **ENSURE THAT THE SAFETY NET IS TAUT AND SECURED TIGHTLY (NO SAGGING)**

THE SAFETY NET WILL NOT FUNCTION PROPERLY OTHERWISE

SECURE THE NET ENTRANCE WHEN TRAMPOLINE IS IN USE!

CARE AND MAINTENANCE

GENERAL: Your trampoline is designed for year-round outdoor use, so it generally requires very little maintenance. However, a little care and forethought can add years to your trampoline's life. Remember that the bed (mat), and frame pads are made of synthetic materials and are easily damaged by cigarette ends, fireworks and bonfire debris.
With all products it is vital that the equipment is checked regularly and often by an adult. The complete product should be checked at least once a month and particular attention should be paid to connections and fastenings. If any parts exhibit signs of wear and tear, they may need to be replaced. Failure to do this may result in the product malfunctioning and causing an injury. The product must not be used until properly and fully installed and checked.

FRAME: Do not sit or stand on the frame or the frame pads while the trampoline is in use as this restricts the frame's natural reflex action. If surface rust appears it should be removed with either a wire brush or coarse sandpaper, and the area treated with a non-toxic paint.

FRAME PAD: Frame pads are there to protect the user from any accidental fall or landing on the springs and frame. On NO account should people be permitted to sit or stand on them when the trampoline is in use. You should also make sure that smaller users do not use the inside edges of the pads as a "handle" when getting up on to the trampoline.**THE MAT:** The mat (bed) will, over the years, be gradually weakened by the effects of ultra violet radiation. Therefore, the more it can be protected from direct sunlight the longer it will last. A little mold or mildew should not harm the mat. Do make sure that shoes are removed before bouncing and ensure that any other sharp objects such as belt buckles, brooches, and jewelry are also not worn.

THE ENCLOSURE: Never use the Enclosure Poles or Safety Net as a handhold or grip to assist in entering or exiting the trampoline. This will result in damage to your Enclosure, for which Pure Fun™ is not responsible.
Never attempt to rebound off of, swing or hang from the Safety Net or Enclosure poles, nor intentionally attempt to jump into or over the netting, as this may result in serious injury, paralysis or death and severe damage to the Enclosure and Trampoline. Pure Fun™ is not responsible for any damage to the Trampoline and Enclosure or consequential injuries resulting from the above practices.

THE SPRINGS: NEVER stand on the springs while the trampoline is in use. Try not to bounce near the springs. They are not designed for this sort of stress and can become stretched and weakened. If you find you have any damaged or stretched springs, it is important to replace them as soon as possible to avoid potential damage to the trampoline mat and tension overload on the remaining good springs.

IMPORTANT:
This trampoline was designed and manufactured with quality materials and craftsmanship. With proper care and maintenance, it will provide all jumpers with years of exercise, fun, and enjoyment. Please follow the guidelines below:
This trampoline is designed to withstand a specific weight and usage. Ensure only one person uses the trampoline at any one time. People over 250 pounds (113kgs) should not use the trampoline. Jumpers should wear socks, gymnastics shoes, or be barefoot when using the trampoline. Street shoes or tennis shoes should NOT be worn while using the trampoline. To limit damage, do not allow pets onto the mat. Jumpers should remove all sharp objects from their person prior to using the trampoline. All sharp or pointed objects should be kept off the trampoline mat at all times.
Always inspect the trampoline before each use for worn, damaged or missing parts.

LOOK FOR:
Punctures, holes, or tears in the trampoline mat or safety netting
Sagging trampoline mat or netting
Loose stitching or any kind of deterioration of the mat or netting
Bent or broken frame parts, especially the legs, top rail and enclosure poles
Broken, missing, or damaged springs
Damaged, missing, or insecurely attached frame pad
Protrusions of any type (especially sharp) on the frame, spring, or mat.

No modification should be carried out to the trampoline, the enclosure or any of its components. Any modification could lead to damage to the product or to personal injury.

IF YOU FIND ANY OF THE PREVIOUS CONDITIONS, OR ANYTHING ELSE THAT YOU FEEL COULD CAUSE HARM TO ANY USER, THE TRAMPOLINE SHOULD BE DISASSEMBLED OR SECURED FROM USE UNTIL THE CONDITION(S) HAS BEEN RECTIFIED.

TO DISASSEMBLE AND/OR MOVE

IN WINDY CONDITIONS - In severe wind conditions, the trampoline can be blown about. If you expect windy weather conditions, the trampoline should be moved to a sheltered area or disassembled. To ensure security in normal weather conditions, at least four (4) tie downs should be used. Secure the trampoline frame to the ground. You can purchase an ANCHOR KIT for your trampoline from Pure Fun, by visiting us on the web at www.pureglobalbrands.com or by calling 866-498-5269. It is insufficient to secure only the legs of the trampoline to the ground as they can pull out the frame sockets.

MOVING THE TRAMPOLINE - When moving the trampoline, **a minimum of three people are required**. All connecting points on the top rails should be securely and tightly wrapped with weather resistant tape, such as duct tape. This will keep the frame intact during the move and prevent the connector points from dislocating and separating. When moving, lift the trampoline slightly off the ground and keep it horizontal to the ground. Never drag the trampoline. For any type of other move, you should disassemble the trampoline. After any move please conduct a full safety inspection.

TO DISASSEMBLE:

ADULTS REQUIRED – A rubber mallet (not included) is required to disassemble some parts of the trampoline.

1. Unattach the Enclosure Netting by unclasping the net bottom, and then releasing the hoops at the top. Fold and store the net neatly where it will not be damaged or torn.

2. Remove the Enclosure hardware (Steel Jigs, Spacers, etc.) attaching the poles to the trampoline. Store this hardware in a resealable zippered plastic bag for later reassembly. Remove and store the poles in a dry, safe location where they will not present a tripping hazard or become damaged.

3. The Leg Extension (#6) and T-section assemblies (#4) are very tight and do not disassemble easily. We suggest you use a lubricant **before** beginning disassembly, specifically on the areas where the T-section and Leg Extension come together. You should lightly lubricate the visible joint by the flanged end of the Leg Extension, and apply a small amount of lubricant down the tube of the Leg Extension. After applying lubrication, **make sure to clean excess lubricant from any exterior surfaces using a degreasing agent.** Making sure there is no lubricant/grease on the Leg extension exterior or the striking surface on the top rail, firmly grip or clamp the Leg Extension and use a rubber mallet hit the top rail (#3) as shown to the right to disassemble this part.

Before reassembly or storage, any remaining lubricant must be fully cleaned with a degreasing agent to ensure that the metal does not become damaged and that proper reassembly is achieved. (See diagram 3.)

4. Do **NOT** disassemble the T-section (#4) and the top rail (#3); you can keep it as it is. It is not necessary and it will make re-assembly easier. (See diagram 4)

3.



4.



INFORMATION ON USE OF THE TRAMPOLINE

Initially, get accustomed to the feel and bounce of the trampoline. The focus must be on the fundamentals of your body position and you should practice each bounce (the basic bounces) until you can perform each with ease and control.

To break a bounce, flex your knees sharply before your feet come in contact with the mat.
This technique should be practiced as you are learning each of the basic bounces.
The skill of braking should be used whenever you lose balance or control of your jump.

Always learn the simplest bounce first and be consistent with the control of your bounce before moving on to more difficult and advanced bounces. A controlled bounce is when your take off point and landing point is the same spot on the mat. If you move up to the next bounce without first mastering the previous, you increase your risk of injury.

Do not bounce on the trampoline for extended periods of time as fatigue can increase your risk of injury. Bounce only for a brief period of time. Only one person should bounce on the trampoline at a time.

Never intentionally bounce into, climb on, or hang from the enclosure poles or netting.

Never climb over or crawl under the netting to enter or exit the trampoline enclosure.

Jumpers should wear a t-shirt, shorts or sweats, and regulation gymnastics shoes, heavy socks, or be barefoot. If you are just beginning, you may want to wear long sleeve shirts and pants to protect against scrapes and abrasions until you master correct landing positions and form. Do not wear hard sole shoes, such as tennis shoes on the trampoline as this will cause excessive wear on the mat.
You should always mount and dismount properly in order to avoid injury. To mount properly, you should place your hand on the frame and step or roll up onto the frame, over the springs, and onto the trampoline mat. Always remember to place your hands onto the frame while mounting or dismounting. Do not step directly onto the frame pad or grasp the frame pad. To dismount properly, move to the side of the trampoline and place your hand onto the frame as a support and step from the mat to the ground. Smaller children should be assisted when mounting and dismounting.

Do not bounce recklessly on the trampoline, as this will increase your risk of injury. The key to safety and having fun on the trampoline is control and mastering the various bounces. Never try to outbounce another bouncer in terms of height!

Never allow use of the trampoline by minors without ADULT supervision.

SAFETY CONCERN SITUATIONS:

Mounting and Dismounting: Be very careful when getting on and off the trampoline. DO NOT mount the trampoline by grabbing the frame pad, pulling on the enclosure poles, stepping onto the springs, or by jumping onto the mat from any surface (e.g. a deck, roof, or ladder) as this will increase your risk of injury.
DO NOT dismount by jumping off the trampoline. If small children are playing on the trampoline, they may need help in mounting and dismounting. Always zipper shut the enclosure doorway when the trampoline is in use, and secure the trampoline against unauthorized use by locking the enclosure zipper after use.

Use of Alcohol or Drugs: DO NOT consume any alcohol or drugs before or while using this trampoline as this will impair your judgment, reaction time, and overall physical coordination.

Multiple Jumpers: NEVER have multiple jumpers (more than one person on the trampoline at any one time), as you increase the chance of getting injured or damaging the trampoline. Injuries could occur when you fly off the trampoline, lose control, collide with the other jumper(s), or land on the springs. Generally, the lightest person on the trampoline will get injured.

Striking the Frame or Springs: When playing on the trampoline, STAY in the center of the mat. This will reduce your risk of injury from the frame or springs. Always keep the frame pad on the frame DO NOT jump or step onto the frame pad; it is not intended to support the weight of a person.

Jumping into the Enclosure Poles or Netting: NEVER attempt to rebound off of, swing or hang from the Safety Net or Enclosure poles, nor intentionally attempt to jump into or over the netting, as this may result in serious injury, paralysis or death and severe damage to the Enclosure and Trampoline. Pure Fun™ will not be responsible for any damage to the Trampoline and Enclosure or consequential injuries resulting from these practices.

Loss of Control: DO NOT try difficult maneuvers until you have mastered the previous maneuver as this will increase your risk of injury. A controlled jump is when your take off point and landing point are on the same spot on the mat. If you lose control when you are jumping on the trampoline, bend your knees sharply when you land and this will allow you to stop your jump and regain control.

Somersaults (Flips): DO NOT PERFORM somersaults of any type (backwards or forwards) on this trampoline as this will increase your risk of injury to your neck or back, **WHICH MAY RESULT in DEATH OR PARALYSIS.**

Foreign Objects: DO NOT use the trampoline if there are pets, other people, animals or any objects beneath, above or near the trampoline as this will increase the risk of an injury occurring. DO NOT hold any foreign objects in your hand and DO NOT place any objects on the trampoline. Please be aware of what is overhead when you are using the trampoline. Tree branches, wires, or other objects located above the trampoline may result in injury or death.

Poor Maintenance of Trampoline: A trampoline in poor condition will increase your risk of injury. Please inspect the trampoline before each use for bent steel tubes, torn mat, loose or broken springs and overall stability of the trampoline.

Weather Conditions: Please be aware of the weather conditions when using the trampoline. Do not use trampoline if the mat is wet. Do not use the trampoline in windy conditions.

Limiting Access: When the trampoline is not in use, always secure it against access. Remove ladders, step stairs, lock enclosure entryway, etc. to prevent unauthorized and unsupervised access.

LESSON PLAN

The following lessons are recommended in order to learn basic steps and bounces before moving onto more difficult or complicated bounces. You should read and understand all safety instructions before mounting the trampoline. A complete discussion and demonstration of body mechanics and trampoline guidelines should occur between the supervisor and student.

Lesson 1

A. Mounting and Dismounting - Demonstration of proper techniques
B. The Basic Bounce-Demonstration and practice
C. Braking (Check the Bounce) - Demonstration and practice. Learn to stop on command
D. Hands and knees - Demonstration and practice. Stress should be on four- point landing and alignment

Lesson 2

A. Review and practice of techniques learned in Lesson 1
B. Knee Bounce-Demonstration and practice. Learn the basic down to knee and back up before trying half twist to left and right
C. Seat Bounce -Demonstration and practice. Learn basic seat bounce then add a knee bounce, hands and knees; repeat.

Lesson 3

A. Review and practice skills and techniques learned in previous lessons
B. Front Drop-All students should be requested to assume the prone position (face down on the ground) while the instructor checks for faulty positions that could cause injury
C. Start with a hands and knees bounce and then extend body into prone position, land on the mat and return to feet
D. Practice Routine-Hands and knees Bounce, Front Bounce, back to feet, seat bounce, back to feet.

Lesson 4

A. Review and practice skills and techniques learned in previous lessons
B. Half-Turn
- Start from front drop position. As you make contact with the mat, push off with arms in either the right or left direction and turn head and shoulders in same direction.
- During turn, be sure to keep back parallel to mat and head up
- After completing turn, land in front drop position

After completing this lesson, the student now has a basic understanding of trampoline bounces. Jumpers should be encouraged to develop their own routines with emphasis on control and form. A game that can be played in order to encourage students to try and develop routines is “BOUNCE”. In this game, players count off from 1 to 10. Player one starts with a maneuver. Player two has to do Player One’s maneuver and add on another. Player Three does the maneuvers of One and Two and then adds a third maneuver. This continues until a player cannot do the routine properly in the correct sequence. The first person to miss receives the letter “B”. This continues until someone spells out the word “BOUNCE”. The last remaining contestant is deemed the winner! Even when playing this game, it is important to perform your routines under control. Do not try difficult or highly skilled bounces that you have not yet mastered.

A certified trampoline instructor should be contacted to further develop your trampoline skills.

BASIC TRAMPOLINE BOUNCES

THE BASIC BOUNCE
Start from standing position, feet shoulder width apart and head up and eyes on mat. Swing arms forward, up and around in a circular motion. Bring feet together while in mid-air and point toes Downward Keep feet shoulder width apart when landing on mat.



KNEE BOUNCE
Start with basic bounce and keep it low Land on knees keeping back straight, body erect. Use arms to maintain balance. Bounce back to
basic bounce position by swinging arms up



SEAT BOUNCE
Land in a flat sitting position. Place hands on mat besides hips Return to erect position by pushing with hands.



FRONT BOUNCE
Start with a low bounce Land in prone (face down) position and keep hand and arms extended forward on mat Push off the mat with arms to return to standing position.



180-DEGREE BOUNCE
Start with front bounce position Push off with left or right hands and arms (depending on which way you wish to turn) Maintain head and shoulders in the same direction and keep back parallel to mat and head up Land in prone position and return to standing position by pushing up with hands and arms



FREQUENTLY ASKED QUESTIONS

Question: "I need to mow the grass under my trampoline" or "I need to move my trampoline across the yard. What is the best way to do this?"

Answer: ONCE YOUR TRAMPOLINE IS ASSEMBLED, MOVING IT OVER DISTANCES REQUIRES THAT YOU USE AT LEAST 3 ADULTS PLACED EQUIDISTANT AROUND THE TRAMPOLINE.
DURING THE MOVE, YOU MUST LIFT WHILE KEEPING IT LEVEL TO AVOID DAMAGE TO THE UNIT.
MOVING THE TRAMPOLINE FOR MEDIUM/LONG DISTANCES AND/OR OVER UNEVEN GROUND REQUIRES THAT YOU TAPE THE TOP RAIL FRAME JOINTS TO PREVENT SLIPPAGE.
NEVER DRAG YOUR TRAMPOLINE IN ORDER TO MOVE IT!

Question: "My frame pad keeps shifting after just a few minutes of use. What can I do?"

Answer: YOU PROBABLY HAVE YOUR FRAME PAD TOO TIGHT. RESEAT THE PAD BY TAKING IT COMPLETELY OFF, AND FOLLOWING THE DIRECTIONS IN STEP 5. REMEMBER; DO NOT TRY TO STRETCH THE ELASTIC BANDS TO THEIR TIGHTEST POINT. THE BANDS NEED SOME GIVE AS THE JUMP MAT THEY ARE ATTACHED TO WILL MOVE SIGNIFICANTLY WHEN SOMEONE IS JUMPING ON THE TRAMPOLINE.

Question: "I need to order springs," "I need to order a new frame pad" or "I need replacement enclosure parts, who do I contact?"

Answer: YOU CAN PURCHASE SPRINGS, FRAME PADS, JUMP MATS, AND EVEN LARGE STEEL DIRECTLY FROM PURE FUN. PLEASE SUBMIT YOUR REQUEST VIA E-MAIL AT: customerservice@puregbi.com, OR YOU CAN CALL 888-498-5269 TO SPEAK WITH A REPRESENTATIVE. IF YOU STILL HAVE YOUR PROOF OF PURCHASE, YOU MAY BE ELIGIBLE FOR A DISCOUNTED RATE EVEN IF YOU ARE OUT OF WARRANTY.

Question: "Something was missing from the packaging," or "I discovered a damaged piece. What should I do?"

Answer: CONTACT PURE FUN CUSTOMER SERVICE AT: customerservice@puregbi.com or by calling 888-498-5269. YOU MUST HAVE YOUR PROOF OF PURCHASE AND/OR ORDER CONFIRMATION AVAILABLE TO BE CONSIDERED FOR WARRANTY REPLACEMENT. YOU MUST REPORT MISSING PIECES WITHIN 30 DAYS FROM DATE OF PURCHASE. PLEASE BE AWARE THAT UNDER OUR LIMITED WARRANTY, FOR SOME PARTS WE REQUIRE A PICTURE OF THE DAMAGED ITEM AND/OR RETURN OF THE ITEM TO OUR QUALITY CONTROL OFFICE FOR REVIEW.

For more information on this product please visit www.pureglobalbrands.com

Pure Fun Trampoline Accessories

Trampoline Anchor Kit - 9201AK

The Pure Fun Trampoline Anchor Kit is designed to help secure large trampolines against rough weather. Kit includes 4 Tie-down straps, D-rings, and ground anchor stakes. *(15' Trampoline requires 2 Kits to secure)*

15' Trampoline Cover - 9215TC

Pure Fun's all-weather Trampoline Covers protect and prolong the life of your trampoline. Useful in keeping leaves and other debris off of the jumping mat, this heavy duty 130g polythylene cover resists harmful UV rays, rain and snow. *(Requires removal of enclosure assembly to attach)*

12-Pack Replacement Springs - 9202SK

Replacement 7" trampoline springs for all Pure Fun Large Trampolines (12' through 15'). Pack of 12. *(Spring Tool not included)*

Trampoline Ladder - 9200TL

Made from high-carbon steel, this ladder measures 38" high, perfect for added safety in mounting and dismounting Pure Fun trampolines.

CALL 866-498-5269 FOR PRICING AND AVAILABILITY ON THESE ITEMS, OR VISIT www.pureglobalbrands.com